

## X187, S187 Programming Cable FN-V187 VoiceNET Serial Interface Cable FN-P187 Printer Interface Cable




X187 Programming Cable



S187 Programming Cable



FN-V187 VoiceNET Serial Interface Cable



FN-P187 Printer Interface Cable

### APPLICATION

X187 and S187 are used to program the FireNET family of panels.

FN-P187 Printer Interface cable is used to connect a serial printer to the FireNET family of panels.

FN-V187 VoiceNET Serial Interface Cable is used to interconnect a FireNET Panel with a VoiceNET Master Panel.

### SPECIFICATIONS

#### X187/S187:

Cable Type:	FireNET Family Programming
Cable Length:	8.3 feet (2.5 meters)
Left Connector:	10 Pin Serial (Female)
Right Connector:	9 Pin - DB9 (Female)
X187:	Non-Jacketed Version
S187:	Jacketed Version

Continued on back

## SPECIFICATIONS

### FN-V187:

Cable Type:	VoiceNET Integration Cable
Cable Length:	8.3 feet (2.5 meters)
Left Connector:	10 Pin Serial (Female)
Right Connector:	2 Wire Pin (male)

## SPECIFICATIONS

### FN-P187:

Cable Type:	FireNET/FireNET Plus Printer Cable
Cable Length:	8.3 feet (2.5 meters)
Left Connector:	10 Pin Serial (Female)
Right Connector:	25 Pin Serial (male)

## WIRING DIAGRAMS:

